

* LAP SEAM MUST BE ROLLED WITH APPROVED ROLLER.


FILE NAME: WP2095 PLOT DATE: 10/15/07

CENTER #14 OR #15 FASTENER W/ SOPRIFIX 2" PLATE IN SIDELAP SEAM. SEE CURRENT SOPRIFIX PDS FOR INSTALLATION PROCEDURES.

SOPREMA ALSAN RS FIELD MEMBRANE

SOPRIFIX FIELD BASE MEMBRANE PLY

APPROVED SUBSTRATE



SOPRIFIX FIELD BASE MEMBRANE PLY LAYOUT W/ALSAN RS MEMBRANE



310 QUADRAL DRIVE
WADSWORTH, OHIO 44281
(330) 334-0066

TITLE			
ALSAN RS/SOPRIFIX W/2" PLATE & 4" LAP			
SCALE	DWN	CHK	APPROVAL DATE
NONE	DMT	MT	10/15/07
DRAWING NUMBER			REV
A-13-RS			0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.