


NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. ALSAN RS PASTE MAY BE USED TO FILL VOIDS PRIOR TO INSTALLING THE ALSAN RS MEMBRANE STRIP OR TAPE.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE RECOVERY BOARD WATERPROOFING ASSEMBLY			
SCALE	DWN DMT	CHK MT	APPROVAL DATE 3/20/07
DRAWING NUMBER A-3b-RS			REV 0

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.