


INSTALL A 12" (300mm) WIDE STRIP OF SOPRASEAL STICK 1100T BY ADHERING THE FIRST FEW INCHES AT THE TOP AND LEAVING THE RELEASE FILM ON THE REMAINDER OF THE STRIP. OVERLAP END OF STRIPS BY A MINIMUM OF 6" (150mm).

SOPRASEAL STICK 1100T OR SOPRASEAL STICK VP MEMBRANE

**NOTES:**

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.
2. AIR/VAPOR RETARDER TYPE AND PLACEMENT REQUIREMENTS ARE TO BE DETERMINED BY THE SPECIFIER

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066		
		TITLE EXPANSION JOINT		
SCALE	N.T.S.	DWN TM	CHK RS	APPROVAL DATE 4/29/14
DRAWING NUMBER			AB1100T010	REV 0