

APPROVED ELASTOCOL PRIMER


INSTALL A 12" (300mm) WIDE STRIP OF SOPRASEAL STICK 1100T BY ADHERING THE FIRST FEW INCHES AT THE TOP AND LEAVING THE RELEASE FILM ON THE REMAINDER OF THE STRIP. OVERLAP END OF STRIPS BY A MINIMUM OF 6" (150mm).

SOPRASEAL STICK VP MEMBRANE

EXPANSION JOINT WITH SELF-ADHESIVE MEMBRANE

NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.
2. AIR/VAPOR RETARDER TYPE AND PLACEMENT REQUIREMENTS ARE TO BE DETERMINED BY THE SPECIFIER
3. THE USE OF A PRIMER WITH SOPRASEAL STICK VP IS OPTIONAL.

| | | | |
|---|-----|---|---------------|
|  | | 310 QUADRAL DRIVE | |
| | | WADSWORTH, OHIO 44281 (330) 334-0066 | |
| TITLE | | | |
| EXPANSION JOINT | | | |
| SCALE | DWN | CHK | APPROVAL DATE |
| N.T.S. | TM | RS | 4/29/14 |
| DRAWING NUMBER | | | REV |
| ABVP010 | | | 0 |