


NOTES:

1. COLPHENE LIQUID MEMBRANE FILLET SHALL BE INSTALLED AT ALL CORNER TRANSITIONS.
2. PREPARED SUBSTRATE MUST BE PRIMED PRIOR TO INSTALLING COLPHENE 3000 FLASHING STRIPS. ALLOW PRIMER TO CURE APPROPRIATELY BEFORE MEMBRANE INSTALLATION.
3. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE			
OUTSIDE CORNER DETAIL			
SCALE	DWN	CHK	APPROVAL DATE
NONE	TM	RS	10/30/12
DRAWING NUMBER			REV
BGW-10			0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.