


NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. SUBSTRATE MUST BE PROPERLY PREPARED AND PRIMED PRIOR TO THE COLPHENE 3000 APPLICATION.
3. COLD JOINTS SHOULD BE PROPERLY GROUTED.
4. PLEASE REFER TO DETAIL BSW-14 FOR ALTERNATE TIE-IN OPTIONS.
5. TERMINATION BAR ON COLPHENE BSW (F) INSTALLED AT COMPLETION OF THE VERTICAL WALL POUR.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE			
COLPHENE 3000 TIE-IN TO COLPHENE BSW (F)			
SCALE	DWN	CHK	APPROVAL DATE
NONE	TM	JP	04/11/11
DRAWING NUMBER			REV
BGW-8			0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.