

METAL DRIP EDGE—ABRADE & CLEAN FLANGE W/SOPREMA ALSAN RS MEMBRANE CLEANER & SET IN BED OF ACCEPTABLE SEALER.

SOPREMA ALSAN RS MEMBRANE FLASHING—EXTEND FULL WIDTH OF FLANGE & 4" (10cm) MIN. ONTO PREPARED & PRIMED SUBSTRATE.

FASTENERS 4" (10cm) O.C., STAGGERED 1".  
SOPREMA ALSAN RS FIELD MEMBRANE

2" MIN (5cm) 1/4" HEM

4" (10cm)


PREPARE, LEVEL & PATCH SUBSTRATE W/ ALSAN RS PASTE OR ACCEPTABLE PATCHING MORTAR PRIOR TO APPLICATION OF SOPREMA ALSAN RS PRIMER & MEMBRANE (TYP.)

GUTTER & SUPPORT STRAPS BY OTHERS. EXPOSED FASTENERS MUST BE FASTENED ALONG VERTICAL FACE OF DRIP EDGE & USE ACCEPTABLE SEALING WASHERS.

CONTINUOUS CLEAT, FASTENED 6" (15cm) (MAX.)

NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281	
		(330) 334-0066	
TITLE			
GUTTER EDGE FLASHING			
SCALE	DWN	CHK	APPROVAL DATE
NONE	DMT	MT	5/30/07
DRAWING NUMBER			REV
E-3-RS			0

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.