



METAL DRIP EDGE—ABRADE & CLEAN FLANGE W/SOPREMA ALSAN RS MEMBRANE CLEANER & SET IN BED OF ACCEPTABLE SEALER.

SOPREMA ALSAN RS MEMBRANE FLASHING—EXTEND FULL WIDTH OF FLANGE & 4" (10cm) MIN. ONTO PREPARED & PRIMED SUBSTRATE.

FASTENERS 4" (10cm) O.C., STAGGERED 1".  
SOPREMA ALSAN RS FIELD MEMBRANE

2" MIN (5cm) 1/4" HEM

4" (10cm)

EXISTING SBS MOD BIT ASSEMBLY (GRANULATED CAP SHEET)

GUTTER & SUPPORT STRAPS BY OTHERS. EXPOSED FASTENERS MUST BE FASTENED ALONG VERTICAL FACE OF DRIP EDGE & USE ACCEPTABLE SEALING WASHERS.

CONTINUOUS CLEAT, FASTENED 6" (15cm) (MAX.)

NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. PREPARE, LEVEL & PATCH ALL APPLICABLE SUBSTARES W/ ALSAN RS PASTE OR ACCEPTABLE PATCHING MORTAR PRIOR TO THE APPLICATION OF SOPREMA ALSAN RS PRIMER & MEMBRANE (TYP.).

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066		
		TITLE GUTTER EDGE FLASHING—OVER SBS		
SCALE	NONE	DWN TM	CHK RS	APPROVAL DATE 6/20/12
DRAWING NUMBER				REV
E-3a-RS				0

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.