


- NOTES:
1. SOPRA-FLASH UN TO BE USED AT ALL ANGLE TRANSITIONS. CONTACT SOPREMA FOR APPROVED EXCEPTIONS.
  2. MINIMUM 1/4" TO MAXIMUM 1/2" SPACING BETWEEN LENGTHS OF TERMINATION BAR: ADD ADDITIONAL FASTENERS AS NEEDED TO ACHIEVE AND MAINTAIN COMPRESSION OF FLASHING MATERIALS.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281	
		(330) 334-0066	
TITLE BASIC DESIGN			
SCALE	DWN	CHK	APPROVAL DATE
NONE	TM	JP	12/11/09
DRAWING NUMBER HRW-100			REV 0

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.