


NOTES:

1. RE-PRIME EXPOSED SUBSTRATE, AS NECESSARY PRIOR TO THE INSTALLATION OF ANY NEW MATERIALS
2. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE			
REPAIR PATCH / TIE-IN			
SCALE	DWN	CHK	APPROVAL DATE
NONE	TM	JP	11/23/09
DRAWING NUMBER			REV
HR-303			0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.