


NOTES:

1. SOPRA-FLASH UN MUST BE USED AT ALL IRREGULAR SURFACE TRANSITIONS AND ALL DISSIMILAR SUBSTRATES, I.E. CONCRETE TO GYPSUM BOARD, CONCRETE TO WOOD, ETC.
2. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
3. STAIR / STEP WALL TRANSITION REINFORCEMENT TO BE USED IN CONJUNCTION WITH APPROVED COLPHENE H WATERPROOFING ASSEMBLY. CONTACT SOPREMA.
4. COLPHENE 180 SANDED IF USED DOES NOT REQUIRE AN ADDITIONAL PROTECTION COURSE. CALL SOPREMA FOR DETAILS

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE WALL STEP-UP FLASHING DETAIL			
SCALE	NONE	DWN TM	CHK JP
DRAWING NUMBER			APPROVAL DATE
HRW-600			11/25/09
			REV 0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.