


NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.
2. FOR SPECIFIC INSTALLATION REQUIREMENTS, CONTACT SOPREMA.
3. FILL ALL VOIDS IN JOINTS. ALL JOINTS GREATER THAN 1/4" MUST BE REINFORCED WITH SOPRA-FLASH UN.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE PLYWOOD DECK-REINFORCED HR-TONGUE & GROVE PLYWOOD			
SCALE	NONE	DWN TM	CHK JP
DRAWING NUMBER		APPROVAL DATE	
HRW-605		11/25/09	
			REV 0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.