



NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. METAL SURFACES MUST BE CLEANED AND ABRADED TO COMPLETELY REMOVE ALL COATINGS, DIRT AND DEBRIS. AFTER GRINDING, WIPE ABRADED METAL WITH SOPREMA ALSAN RS CLEANER AND ALLOW TO FLASH OFF BEFORE APPLYING SOPREMA ALSAN RS MEMBRANE.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066		
		TITLE SUPPORT BRACKET PENETRATION FLASHING		
SCALE	NONE	DWN DMT	CHK MT	APPROVAL DATE 3/20/07
DRAWING NUMBER P-11-RS				REV 0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.