


NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPROVED DETAILS AND R-NOVA + APPLICATION AND COVERAGE DIRECTIONS.
2. R-NOVA + FIELD ASSEMBLY AND SEAM REINFORCEMENT NOT SHOWN FOR CLARITY.
3. R-NOVA + MASTIC IS APPLIED ONLY AFTER THE FASTENERS HAVE BEEN PROPERLY TIGHTENED.
4. FASTENERS AND ALL METAL MUST BE CLEANED WITH SOPREMA ALL PURPOSE CLEANER PRIOR TO THE APPLICATION OF R-NOVA + MASTIC (TYP.).

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE R-NOVA + FASTENERS			
SCALE NONE	DWN TM	CHK RS	APPROVAL DATE 04/19/12
DRAWING NUMBER R-NOVA+ 008			REV

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.