



- NOTES:
1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.
  2. EXTEND APPROVED SOPRASEAL FLASHING MEMBRANE A MINIMUM OF 3" ONTO THE PROPERLY INSTALLED COLPHENE 3000. APPLY ELASTOCOL STICK OR ELASTOCOL STICK ZERO PRIMER ON COLPHENE 3000 TIE-IN PRIOR TO INSTALLING THE SOPRASEAL MEMBRANE.
  3. REQUIRED COUNTERFLASHING NOT SHOWN FOR CLARITY.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE X-PRESS G WALL FOUNDATION JUNCTION			
SCALE NONE	DWN TM	CHK RS	APPROVAL DATE 05/14/14
DRAWING NUMBER SXG-01b			REV X

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.