


INSTALL A 12" WIDE STRIP OF SOPRASEAL STICK 1100T BY ADHERING THE FIRST FEW INCHES AT THE TOP AND LEAVING THE RELEASE FILM THE REMAINDER OF THE STRIP. OVERLAP END OF STRIPS BY A MINIMUM OF 6".

SOPRASEAL XPRESS G  
SOPRASEAL STICK 1100T

NOTES:  
1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE EXPANSION JOINT FLASHING			
SCALE	NONE	DWN TM	CHK RS
DRAWING NUMBER		APPROVAL DATE	
SXG-08		05/14/14	
			REV X

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.