



(i): Always install Sopradrain filter fabric towards soil retention system. Primer is recommended over drainage board for application below 50°F.

COPYRIGHT 2016 SOPREMA



SOPREMA

310 Quadral Drive
Wadsworth, OH 44281
WWW.SOPREMA.US
Tel: 330.334.0066

TITLE: **BLIND SIDE WATERPROOFING
VERTICAL DETAIL**

PROJECT:		DRAWING NUMBER:
SCALE: N.T.S.	DATE: NOVEMBER 2015	BSW17