



NOTE:
 1. REMOVE PLASTIC FILM FROM BACKSIDE OF COLPHENE BSW H MEMBRANE BY TORCH OR HOT AIR WELDER PRIOR TO APPLICATION OF PRIMER & COLPHENE LIQUID MEMBRANE.

NOTE: REFER TO SOPREMA RELATED PUBLISHED DOCUMENTATION, PRODUCT DATA SHEETS (PDS) & SAFETY DATA SHEETS (SDS) FOR ADDITIONAL INFORMATION. ALL DETAIL DRAWINGS & RELATED INSTALLATION GUIDELINES ARE PROVIDED BY SOPREMA FOR THE SOLE PURPOSE OF SOPREMA WARRANTY QUALIFICATION. ACCORDINGLY, ANY DETAILS DRAWINGS PROVIDED ARE NOT OFFERED AND SHOULD NOT BE CONSIDERED A SUBSTITUTE FOR PROFESSIONAL DESIGN SERVICES. USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL, PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.

310 QUADRAL DRIVE
 WADSWORTH, OHIO 44281
 (330) 334-0066



STANDARD TIE-IN DETAIL				DRAWING NO.: STD-01
COLPHENE 3000 TO COLPHENE BSW-H				
REVISION	ISSUE DATE	SCALE	DRAWN BY	
0	12-20-2016	N.T.S.	DRW	

SST_001