


NOTES:

1. SUBSTRATE MUST BE PRIMED PRIOR TO THE INSTALLATION OF NEW MATERIALS.
2. COMPLETELY ENCAPSULATE REINFORCEMENT WITH A TOP COAT OF ALSAN RS FLASH IMMEDIATELY AFTER INSTALLATION. DO NOT LEAVE EXPOSED OVERNIGHT.
3. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.

| | | | |
|--|-----|-----------------------|---------------|
|  | | 310 QUADRAL DRIVE | |
| | | WADSWORTH, OHIO 44281 | |
| | | (330) 334-0066 | |
| TITLE | | | |
| ALSAN RS ISOMETRIC THRESHOLD DETAIL | | | |
| SCALE | DWN | CHK | APPROVAL DATE |
| NONE | TM | GP | 06/07/10 |
| DRAWING NUMBER | | | REV |
| M-8-RS | | | 0 |

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.