


NOTES:

1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. REFER TO PRODUCT DATA SHEETS ON WEB SITE FOR FURTHER INFORMATION. www.soprema.us
3. THE DRIP EDGE IS INSTALLED OVER THE SOPREMA ROOF UNDERLAYMENT.
4. INSTALL SOPREMA ROOF UNDERLAYMENT TO FORM WATER-SHEDDING LAPS.
5. REPAIR ALL HOLES LEFT FROM REMOVAL OF TOE BOARDS, ROOF JACKS, ETC.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281	
		(330) 334-0066	
TITLE			
SOPREMA ROOF UNDERLAYMENT EAVE DETAIL			
SCALE	DWN	CHK	APPROVAL DATE
NONE	DMT	ECS	10/15/09
DRAWING NUMBER			REV
			0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.