

ALSAN RS FLASH MEMBRANE
TURN DOWN OUTSIDE FACE
OF WALL AS REQUIRED.

REGLET

ALSAN RS FIELD
MEMBRANE

ALSAN RS FLASH MEMBRANE
BASE FLASHING - SEE
TYPICAL DETAILS

NOTE:
SIZE WIDTH OF DE-BONDING TAPE TO PROVIDE
UN-ADHERED AREA MINIMUM 5 TIMES LARGER
THAN THE MAXIMUM ANTICIPATED EXPANSION.
MEMBRANE COVER STRIP MUST EXTEND PAST
DE-BONDING TAPE 4" MINIMUM ALL SIDES (TYP.)

VIEW @ PARAPET WALL

FILL VOID BETWEEN ALSAN RS FLASH MEMBRANE &
REGLET W/ ALSAN RS PASTE OR ACCEPTABLE
FILLER AS REQUIRED.

ALSAN RS FLASH MEMBRANE - PRESATURATED
EDGE TUCKED INTO 1/2" MINIMUM DEEP SAW-CUT
REGLET BOTH SIDES OF JOINT (TYP.)

FILL JOINT W/ ALSAN RS PASTE OR ACCEPTABLE
FILLER AS REQUIRED.

PREPARE, LEVEL & PATCH SUBSTRATE
W/ALSAN RS PASTE OR ALSAN RS MORTAR
AFTER PRIMING & PRIOR TO APPLICATION
OF ALSAN RS FLASH MEMBRANE (TYP.)

2" (+/-5 cm)
(MIN.)

LINE OF ALSAN RS FLASH MEMBRANE BASE
FLASHING BELOW

(1) PLY ALSAN RS FLASH MEMBRANE
STRIP COVERING ENTIRE JOINT
IN PARAPET WALL.


DE-BONDING TAPE SIZED TO ACCOMODATE
MOVEMENT & CENTERED OVER JOINT.

SECTION THRU JOINT

SCALE: NTS

NOTE: REFER TO SOPREMA RELATED PUBLISHED DOCUMENTATION, PRODUCT DATA SHEETS (PDS) & SAFETY DATA SHEETS (SDS) FOR ADDITIONAL INFORMATION. ALL DETAIL DRAWINGS & RELATED INSTALLATION GUIDELINES ARE PROVIDED BY SOPREMA FOR THE SOLE PURPOSE OF SOPREMA WARRANTY QUALIFICATION. ACCORDINGLY, ANY DETAILS DRAWINGS PROVIDED ARE NOT OFFERED AND SHOULD NOT BE CONSIDERED A SUBSTITUTE FOR PROFESSIONAL DESIGN SERVICES. USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL, PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.

310 QUADRAL DRIVE
WADSWORTH, OHIO 44281
(330) 334-0066



SOPREMA[®]

**ALSAN RS WATERPROOFING MEMBRANE
WALL BASE FLASHING (STRIPPED JOINT)**

DRAWING NO.:
RS-J4D

REVISION

0

ISSUE DATE

12-15-2018

SCALE

N.T.S.

DRAWN BY

DRW

RS_J04D