

SOPREMA ALSAN RS MEMBRANE FLASHING APPLIED EDGE TO EDGE OVER EXISTING PREPARED & PRIMED COPING STONE.

EXISTING COUNTERFLASHING TO BE REMOVED & DISCARDED.

PREPARE, LEVEL & PATCH SUBSTRATE W/ ALSAN RS PASTE OR ACCEPTABLE PATCHING MORTAR PRIOR TO APPLICATION OF SOPREMA ALSAN RS PRIMER & MEMBRANE (TYP.)

(1) PLY SOPREMA ALSAN RS MEMBRANE FLASHING EXTEND 4" (10cm) MIN. HORIZONTALLY ONTO PREPARED & PRIMED STRUCTURAL DECK.


ACCEPTABLE FILL MATERIAL TO MATCH HEIGHT OF EXISTING WATERPROOFING ADHERED TO SOPREMA ALSAN RS MEMBRANE (TYP.)

(1) PLY SOPREMA ALSAN RS MEMBRANE FLASHING EXTEND 10" (25cm) MIN. HORIZONTALLY ONTO EXISTING BUR MEMBRANE.

PRE-SATURATE TOP & BOTTOM EDGE OF SOPREMA ALSAN RS FLEECE W/COATING, TUCK INTO 1" MIN. DEEP SAW-CUT REGLET & FILL VOID W/SOPREMA ALSAN RS COATING.

EXISTING GRANULATED BUR MEMBRANE TO REMAIN. CUT BACK BUR MEMBRANE AS REQUIRED FOR SOPREMA ALSAN RS TIE-IN.

NOTES:
 1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066		
		TITLE PARAPET WALL FLASHING (I)		
SCALE	NONE	DWN DMT	CHK MT	APPROVAL DATE 5/30/07
DRAWING NUMBER				REV
B-11a-RS				0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.