


DRAWING MUST BE VIEWED IN ADOBE READER TO ENABLE CUSTOM LAYERING


REMOVE ANY LOOSE OR DAMAGED MEMBRANE,
REPLACE ANY WET OR DAMAGED UNDERLYING
MATERIALS WITH LIKE KIND, PRIME UNDERLYING
MATERIALS AS REQUIRED TO RECEIVE REPAIR MATERIAL



STEP 1

EXTEND BASE PLY A MINIMUM
OF 6" BEYOND DAMAGED AREA

POLYESTER REINFORCED BASE PLY, HEAT WELDED



STEP 2

POLYESTER REINFORCED BASE PLY, HEAT WELDED

ALSAN RS

POLYESTER REINFORCED CAP SHEET, HEAT WELDED


REINFORCING FABRIC

GRANULES

WHEN POSSIBLE, INSTALL REPAIR MATERIAL
MATERIAL THE FULL WIDTH OF EXISTING CAP
SHEET BETWEEN SIDE LAPS

LIQUID MEMBRANE CUT AWAY FOR CLARITY

EXTEND REINFORCING FABRIC A MINIMUM
OF 8" BEYOND BASE PLY
EXTEND CAP SHEET A MINIMUM OF
6" BEYOND BASE PLY
EXTEND ALSAN RS A MINIMUM OF
1/4" BEYOND REINFORCING FABRIC



STEP 3

NOTES:

1. SOPREMA DETAIL DRAWINGS: REFER TO SOPREMA AND OTHER RELATED PUBLISHED DOCUMENTATION, PRODUCT DATA SHEETS (PDS) AND SAFETY DATA SHEETS (SDS) FOR ADDITIONAL INFORMATION. ALL DETAIL DRAWINGS AND RELATED INSTALLATION GUIDELINES ARE PROVIDED BY SOPREMA FOR THE SOLE PURPOSE OF ISSUING A SOPREMA WARRANTY. ACCORDINGLY, THE DETAIL DRAWINGS ARE NOT OFFERED, AND SHOULD NOT BE CONSIDERED, AS A SUBSTITUTE FOR PROFESSIONAL DESIGN SERVICES.
2. HOT WORK: THE CONTRACTOR IS RESPONSIBLE FOR DETERMINING APPROPRIATE CONDITIONS TO UTILIZE HEAT-WELDING EQUIPMENT. REFER TO THE NRCA CERTA RECOMMENDATIONS, LOCAL CODES AND BUILDING OWNER'S REQUIREMENTS FOR HOT WORK OPERATIONS.



US CORPORATE ADDRESS
310 QUADRAL DRIVE
WADSWORTH, OHIO 44281
www.soprema.us
Tel: 330.334.0066

PROJECT:

TITLE:

**2 PLY SBS MEMBRANE
MEMBRANE LEAK REPAIR**

DRAWN BY: SOPREMA TECHNICAL SUPPORT, GGALLOWAY

NO.:

REVISION:

DATE:

DATE: 4.8.2016

SCALE: NTS

DRAWING NUMBER:
US.WSBS.02.16